

# CAMERA NEST BOX




Denne multi redekasse er forsynet med et kamera , således at du på PC skærm eller fjernsyn kan følge "livet" i redekassen.  
 Kameraet kan indstilles i position før ophængning (se i øvrigt vejledning/ tegning på tilslutningsmuligheder)  
 Kameraet kan fra huset slukkes og tændes og giver tydelige gode billeder af hvad der foregår i redekassen. Kameraet vil ikke forstyrre fuglene!  
 Denne redekasse kan bruges til mange forskellige fuglearter:  
 Med kobber beskyttelseshullet på: Blåmejser, Sortmejsler, Sumpmejsle.  
 Uden kobberhullet : Spurve , musvit, Rødstjert.  
 Uden det øverste panel, som åben redekasse: Vipstjert, fluesnapper.  
 Redekassen sættes op mellem nord og sydøst!  
 Rens redekassen én gang om året – senest i december.

This multi nest box has a camera – so it is possible to follow the "life" in the nest box from your PC or television.

The camera can be adjusted before setting up ( please see our instruction drawings how to connect)  
 The camera can from your house be swift on or off and will give you quality pictures on your screen, what is going on in the nest box.  
 The camera will not disturb the birds!

This multi nest box can be used for many different birds:  
 With the copper hole on: Bluetit, Marsh Tit, Coal Tit or Wren  
 Without copper hole : Great Tits , Sparrow ect.  
 Without the upper front panel ( as an open nest box ) Robin, Wagtail or spotted Flycatcher  
 Place the nest box between North and South East.  
 Clean the nest box once a year latest in December!



Atr. No. 541830